



FishUSA Premium Big Planer Boards

Instruction Page

Note: Use the image of the planer board for ease of installation (enclosed)

1. Using both pieces of the same angled boards (2) each
2. Fasten the bottom 12" crossbar piece using **flat-head** machine screws. (Tighten 90%)
3. Fasten the top 12" inch cross bar pieces using **round head** machine screws. (Tighten 90%)
4. Fasten the top diagonal 21" (or 24" large boards) crossbar piece using **round-head** machine screws. (Tighten 90%)
5. Once the planer board is assembled, tighten all screws 100% (do not over-tighten)
6. Insert flag in the hole provided

Included in this box:

Diagram:

- (2) Flags
- (3) 12" Aluminum cross braces
- (1) 21" or (24" for large boards) aluminum cross brace
- (8) 14x2 SS round head screws (top brace attachment)
- (8) ¼" SS washers (top brace attachment)
- (4) 14X1.5 SS flat head machine screws (bottom brace attachment)

Eye Bolt Assembly:

- (2) Large SS eye bolts
- (4) Large SS Fender washers
- (2) SS lock washers
- (4) SS nuts

Note: Use a minimum 500# braided line or 300# monofilament planer board tow line.

Made in the U.S.A.
Thank you for your order!
www.FishUSA.com

